

Epson Document Camera – ELPDC11



Switching On / Off the Document Camera

Press the power button to turn on the document camera. It takes about 10 seconds for the document camera to output an image.

When you're done using the document camera; **press the power button twice** to turn it off.

Freezing an Image

Press and release this button to freeze the image.

After freezing the image, you can change your document while leaving the last document image displayed on the screen.

Press the button again to display the new document.

Automatic Focus

Press the **[Focus]** button on the document camera to automatically focus the document.

Useful if you have manually adjusted the camera arm.

Displaying Small Objects Up Close

To display a small object, lower the camera arm.

To further enlarge an object, press the **[Zoom +]** button on the document camera.

Press the **[Zoom -]** button to zoom out.